

# INSTRUCTION FOR USE PRONTO LINE MARKING PAINT

## INSTRUCTION FOR USE

Thoroughly shake drum before use. Place the drum in a line marker fitted with the Drop & Go system. Then simply begin line marking.

# **GENERAL INFORMATION**

- Suitable for all natural turf sports fields.
- The brightness is dependent on the type of nozzle, pump pressure and walking speed used.

### **GENERAL USE**

 Refer to the guide table below to identify the different nozzle types and their features. Use accordingly to ensure you get optimum results from your ProntoLine and the correct nozzle for field conditions

### **AFTER USE**

- Ensure the line marker is immediately flushed after use by inserting the suction spear into a clean drum of water OR use the FastClean™ system fitted to the Prol ineV4
- Please note the pump must be switched on with either flushing process.
- · Use drum within 12 months of opening.



# **APPLICATION**

Nozzle Colour	No of Field/ Drum	Application Type
RED	3 to 4	Light Over Marking
WHITE	2 to 3	Heavy Over Marking
PURPLE	1.5 to 2	Initial Marking

# **AVAILABLE COLOURS**







